


TVS0009_2
TVS0080

Ellie Walnut TV Unit 180
Ellie Oak TV Unit 180







(FR) Notice de Montage -
Utilisation - Entretien

(IT) Istruzioni per il Montaggio,
l'Uso e la Manutenzione

(DE) Montage - Verwendung -
Wartungshandbuch

(ES) Instrucciones de Montaje,
Utilización y Mantenimiento

(EN) Assembly - Use -
Maintenance Manual




Ⓐ x 5 (+1)

M8x40



Ⓑ x 5 (+1)

M8x13




Ⓒ x 5 (+1)

M8x14



Ⓓ x 1

5#



Ⓐ x 5




Ⓑ x 5



Ⓒ x 5



Ⓓ x 1



CHARNIERES / HINGES / BISAGRA / CERNIERA / SCHARNIER

FR

EN

ES

IT

DE

