


TVS0053_3

Sina-Mango and Rattan TV Stand 145





(FR) Notice de Montage -
Utilisation - Entretien

(IT) Istruzioni per il Montaggio,
l'Uso e la Manutenzione


(DE) Montage - Verwendung -
Wartungshandbuch

(ES) Instrucciones de Montaje,
Utilización y Mantenimiento

(EN) Assembly - Use -
Maintenance Manual



JCB ALLEN BOLT - 6 x 20mm



A x6

WASHER - 8 x 17mm




B x6

ALLEN KEY - 4mm



C x1

LEG



D x2

SHELF





E x3

SHELF PIN



F x12






A x6




B x6





D x2

i





180°



C x1

ii







F x12




E x3

iii




iv





V



vi

